

2011-02-07

Instructions for replacing Launchpad's PCB box
ver 1.00, 2011-02-07

Tools needed: One # 2 Phillips screw driver.

1. Remove the net and uprights.
2. Turn the Launchpad over (turf side down) and remove the USB cable from the retainers.
3. Remove the four screws holding the PCB cover and then remove the cover itself.
4. Spread apart retainers and lift the light guide



5. Lift the PCB box out of recess; take care not to lose any parts.
6. Unscrew the cover from the replacement PCB box.
7. Drop the replacement PCB box into the recess.
8. Set the light guide in place.



9. Re-thread USB cable through the wire retainers.



10. Close the PCB cover.